


# SP500, HD550 DOLLY JACK ASSEMBLY - 039578

#	PART #	DESC.	QTY.
1.	039091	DOLLY JACK	1
2.	017751	3/8 FW	8
3.	040637	3/8-16 x 2-1/4	4
4.	039095	TIRE	2
5.	010133	PIN, COTTER	2
6.	010464	NYLOK, 3/8-16	4
7.	040661	FRONT JACK	2
8.	039633	DECAL	1
9.	015692	ALEMITE CAP	2
10.	039094	SPACER	2



#	PART #	DESC.	QTY.
1.	039091	DOLLY JACK	1
2.	017751	3/8 FW	8
3.	040637	3/8-16 x 2-1/4	4
4.	039095	TIRE	2
5.	010133	PIN, COTTER	2
6.	010464	NYLOK, 3/8-16	4
7.	040352	REAR JACK	2
8.	039633	DECAL	1
9.	015692	ALEMITE CAP	2
10.	039094	SPACER	2